MODULE

<u>~ 138</u>

MODULE

Fig. 1 100 ~ 110 ACM-MANUFACTURER NETWORK SERVER 104 112 108 102 128 سر <u>\_\_\_ 128</u> 130 SERVICE-NETWORK NETWORK PORTAL GATEWAY COMPUTER SERVER INTERFACE DATABASE <u>~ 108</u> - 116 USER 132 -134 120 System Memory 114 118 -ACM I/O - 122 ACM CPU BACKPLANE INTERFACE ACM BACKPLANE - 138 INTERFACE INTERFACE INTERFACE

MODULE

138





